W

MATERIALS HANDLING


TRUCK COMPONENT | BALL BEARING TURNTABLES



HE and SO series turntables are not suitable for mechanical handling applications, see KDL series on pages 96 97

All turntables supplied primed for corrosion protection

In the case of use above a steered axle or above a fifth wheel on semi-trailers with rear axle steering, please enquire for load data giving details of the vehicle




HE SERIES

FOR DRAWBAR AND SPECIAL TRAILERS

| Α | В | С | D | E * | F * | G | Н | I | approx. weight | load cap. (tonnes) ** | reference |
|------|------|------|------|------|------|----|----|-----------|-------------------|--------------------------|-----------|
| 685 | 700 | 588 | 567 | 657 | 671 | 9 | 80 | undrilled | 32 | 3.00 | HE4 |
| 880 | 895 | 783 | 762 | 852 | 866 | 9 | 80 | 16 | 43 | 5.00 | HE5 |
| 1000 | 1015 | 903 | 882 | 972 | 986 | 9 | 80 | undrilled | 48 | 6.00 | HE6/1000 |
| 1090 | 1105 | 993 | 972 | 1060 | 1074 | 9 | 80 | 18 | 52 | 6.50 | HE6 |
| 1000 | 1008 | 886 | 859 | 960 | 974 | 10 | 90 | undrilled | 63 | 7.00 | HE12/1000 |
| 1100 | 1108 | 986 | 959 | 1060 | 1074 | 10 | 90 | 18 | 69 | 8.00 | HE12 |
| 1000 | 1008 | 886 | 859 | 960 | 974 | 10 | 90 | undrilled | 63 | 8.00 | HE18/1000 |
| 1100 | 1108 | 986 | 959 | 1060 | 1074 | 10 | 90 | 18 | 69 | 10.00 | HE18 |
| 1000 | 1008 | 886 | 859 | 960 | 974 | 10 | 90 | undrilled | 63 | 10.00 | HE1000/22 |
| 1100 | 1108 | 986 | 959 | 1060 | 1074 | 10 | 90 | 18 | 69 | 12.00 | HE1100/22 |
| 1200 | 1208 | 1086 | 1059 | 1160 | 1174 | 10 | 90 | 18 | 76 | 13.00 | HE1200/22 |



- * Recommended drilling measurements for undrilled turntables
- ** For speeds below 30kph, the axial loads may be exceeded by 20% and by 10% for full trailers with 2 axles. Load capacitites given are applicable if the turntable is mounted to the front of a trailer with 3 axles at speeds of up to 105kph and only valid for operation on paved roads and under conditions prevailing in Europe



SO SERIES

FOR DRAWBAR AND SPECIAL TRAILERS

| | Α | В | С | D | E* | F * | G | Н | I | approx. weight | load cap. (tonnes) ** | reference |
|---|------|------|-----|-----|------|------|----|----|-----------|-------------------|--------------------------|-----------|
| | 987 | 1000 | 871 | 844 | 952 | 966 | 10 | 90 | undrilled | 72 | 12.00 | SO1000/24 |
| _ | 1095 | 1108 | 979 | 952 | 1060 | 1074 | 10 | 90 | 18 | 82 | 16.00 | SO1100/24 |



- Recommended drilling measurements for undrilled turntables
- ** For speeds below 30kph, the axial loads may be exceeded by 20% and by 10% for full trailers with 2 axles. Load capacitites given are applicable if the turntable is mounted to the front of a trailer with 3 axles at speeds of up to 105kph and only valid for operation on paved roads and under conditions prevailing in Europe
- 🚹 All dimensions are in **mm** and all loadings are in **kg** unless otherwise stated and are sublect to manufacturer's standard tolerances


HEAD OFFICE & WAREHOUSE: 5 CENTURY PARK PACIFIC ROAD BROADHEATH ALTRINCHAM CHESHIRE WA14 5BJ t: 0161 928 9617 f: 0161 928 7824 e: SALES@VARLEY.CO.UK SCOTLAND, NORTH EAST t: 01698 732523 f: 01698 730947 e: SCOTSALES@VARLEY.CO.UK MIDLANDS, SOUTH t: 01952 462527 f: 01952 460176 e: MIDSALES@VARLEY.CO.UK






TRUCK COMPONENT | BALL BEARING TURNTABLES | FITTING AND MAINTENANCE INSTRUCTIONS







- 1 The ball bearing turntablemust be mounted on a completely flat and rigid base with at least 50% of the circumference adequately supported. Particular attention must be paid to the support of the web section area containing the ball bearing races. Any unevenness under the flanges can be corrected with metal strips or by filling in with plastic metal.
- 2 Each flange must be attached with a minimum of 8 high tensile bolts grade 8.8, preferably M14 x 1.5 or M16 x 1.5 .
 - Do not drill in the area of the type plate (or ball insertion hole which should be located at less than 40° to the direction of travel).
- 3 To ease the shear load on the mounting bolts in the case of horizontal force at least 4 blocks should be welded on immediately adjoining each flange. The ball bearing turntable must not be mounted by means of welding.
- 4 The turntables are lubricated with a lubricant suitable for the type of operation and the adherent operating conditions before they leave the factory, however the turntable must be adequately re-lubricated before the trailer is put into operation for the first time. The re-lubrication should build up a collar of grease in the gap between the 2 rings of the turntable thus preventing ingress of grit and water into the ball races.
- 5 The ball bearing turntable must be lubricated according to use but at least once a month with a lubricant suitable for the type of operation and the adherent operating conditions. While lubricating the A-frame should be turned so that the grease is evenly distributed and a collar of grease is built up in the gap between the two rings. The tightness of the mounting bolts should also be checked.

6 Ball bearing turntables are subject to wear. The limit of wear is reached when the axial play is 3.5mm. This is at the latest the case when the air gap **X** = 0mm at any point on the circumference of the turntable.



All dimensions are in **mm** and all loadings are in **kg** unless otherwise stated

PAGE 97